

Minute Man anchors[®], inc.

INSTALLATION INSTRUCTIONS FOR BARBED ROCK ANCHOR

- Remove soil to Solid Rock.
- Drill 1-1/4" x 8" hole in rock, Minimum 8".
- Drive anchor to bottom of hole.
- Bend Anchor to line of pull.
- Pretension anchor to frame.
- Place soil back in hole.

